

FUNCTION - TURBO HOSE KITS

- The Inlet Hose moves the air from the compressor inlet into the Intercooler, while the Outlet Hose moves air from the Intercooler to the Intake Manifold.
- These hoses experience extreme pressure & temperatures from the turbocharger.
- Includes T-bolt clamps with stainless steel band and bridge along with stainless steel nylon locking nuts.



30+ SKUs currently available

FUNCTION - EGR TUBES

- Exhaust Gas Recirculation (EGR) tubes recirculate gasses coming from the engine, then directs them back into the intake manifold to be burned off to reduce the vehicle's emissions.
- These tubes connect to the EGR valve and EGR cooler to circulate the gases in the system.

60+ SKUs currently available

